





Grenzstelle

— — — — — Eigentumsgrenze

CKW | Kunde

— — — — — Transformatorstation

Übergabeschalter

Messung
CKW



